







1




2



3




**ATTIVAZIONE / PRIMA ACCENSIONE**

mantenere posizionato il dito sul tasto  per 6 secondi consecutivi fino a quando la lampada si accende.


**ACTIVATION / FIRST IGNITION**


keep your finger on key  for 6 consecutive seconds until the lamp turns on.

**AKTIVIERUNG / ERSTE ZÜNDUNG**

taste  6 Sekunden-lang gedrückt halten, bis die Leuchte ein.

**ACTIVATION / PREMIÈRE ALLUMAGE**

maintenez votre doigt sur la touche  pendant 6 secondes consécutives jusqu'à ce que la lampe s'allume.



4

